WARNING MAGNETIC DRILL PRESS

Any piece of equipment can be dangerous if not operated properly. <u>YOU</u> are responsible for the safe operation of this equipment. The operator must carefully read and follow any warnings, safety signs and instructions provided with or located on the equipment. Do not remove, defeat, deface or render inoperable any of the safety devices or warnings on this equipment. If any safety devices or warnings have been removed, defeated, defaced or rendered inoperable, <u>DO NOT USE THIS EQUIPMENT!!!</u>

WARNING: Operating, servicing and maintaining this equipment can expose you to chemicals including Chromium (Hexavalent Compounds) & Chromium 6 (Chromium VI) from steel which are known to the State of California to cause cancer and birth defects or other reproductive harm. To minimize your exposure, avoid breathing dust. For more information go to www.P65warnings.ca.gov

This 120-volt equipment may require a grounded outlet, do not modify plug.

Keep clear of all rotating parts. Make sure to remove the chuck key before engaging drill. Always secure your work.

IMPORTANT SAFETY RULES TO FOLLOW

- 1. Always use a safety chain. Mounting can release when drilling overhead or on a vertical surface.
- 2. Clean the surface before attaching the drill stand to the work surface.
- 3. Do not attach magnetic base to non-magnetic grades of stainless steel. The magnetic base will not hold.
- 4. Wet connections are shock hazards. If plug or connections get wet, turn power off to the outlet before unplugging the drill.
- 5. Keep the work area clean and well-lit at all times.
- 6. Do not operate magnetic drill in explosive atmospheres, such as in the presence of flammable liquids, gases, or dust.
- 7. Keep bystanders, children, and visitors away while operating a magnetic drill.
- 8. Grounded tools must be plugged into an outlet properly installed and grounded in accordance will all codes and ordinances.
- 9. Avoid body contact with grounded surfaces such as pipes, radiators and ranges.
- 10. Dress properly. Do not wear loose clothing or jewelry. Keep your hair, clothing, and gloves away from moving parts at all times.
- 11. Avoid accidental starting. Be sure switch is off before plugging drill in.
- 12. Always wear eye protection.
- 13. Do not force tool. Do not use tool if switch does not turn it on or off.
- 14. Disconnect the plug from the power source before making any adjustments, changing accessories, or storing the drill.

If the person receiving this handout will not be the user of the equipment, forward these instructions to the operator. If there is any doubt as to the operation or safety of the equipment,

DO NOT USE!!! CALL A TOOL SHED IMMEDIATELY!!!
FAILURE TO FOLLOW THESE INSTRUCTIONS COULD RESULT IN INJURY OR DEATH